


庄銀タクト鶴岡 照明設備

2019/07時点



フルカラーLED UH	下手					中央					上手				
	I	R	G	B	W	I	R	G	B	W	I	R	G	B	W
	255	256	257	258	259	260	261	262	263	264	265	266	267	268	269

4 S U S	調光器①				調光器②				調光器③				調光器④				調光器⑤			
	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118

3 S U S	調光器①				調光器②				調光器③				調光器④				調光器⑤			
	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98

2 S U S	調光器①				調光器②				調光器③				調光器④				調光器⑤			
	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78

フルカラーLED 2bo (スクリーンと共)	下手					中央					上手				
	I	R	G	B	W	I	R	G	B	W	I	R	G	B	W
	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

1 B L	調光器①				調光器②				調光器③				調光器④				調光器⑤				調光器⑥				調光器⑦			
	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58

フルカラーLED 1bo (1 B Lと共)	下手					中央					上手				
	I	R	G	B	W	I	R	G	B	W	I	R	G	B	W
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

P.S.U.S	調光器①				調光器③			調光器②			
	205	206	207	208	213	214	215	209	210	211	212

C.L.

1CL 1.5kw トツ 32台 750w SF-4 10° 4台	上段1	上段2	上段3	上段4	上段5	上段6		上段7	上段8	上段9	上段10		上段11	上段12	上段13	上段14	上段15	上段16
	159	160	163	164	167	168	SF-4	172	173	176	177	SF-4	181	182	185	186	189	190
	下段1	下段2	下段3	下段4	下段5	下段6	171	下段7	下段8	下段9	下段10	180	下段11	下段12	下段13	下段14	下段15	下段16
	161	162	165	166	169	170		174	175	178	179		183	184	187	188	191	192

下FR			
1-1	1-2	1-3	1-4
119	120	121	122
2-1	2-2	2-3	2-4
123	124	125	126
3-1	3-2	3-3	3-4
127	128	129	130
4-1	4-2	4-3	4-4
131	132	133	134
SF1	SF2	SF3	SF4
135	136	137	138

1kw トツ 4台4色
SF-4 26° 2台 /SF-4 zoom 2台

2 C L	2 C L 750kw SF-4 10° 上下6台													
	下1	下2	下3	下4	下5	下6		上1	上2	上3	上4	上5	上6	
	193	194	195	196	197	198		199	200	201	202	203	204	

客席 D L							
349	350	351	352	353	354	355	356
							非常灯連動
357	358	359	360	361	362	363	364

上FR			
1-1	1-2	1-3	1-4
139	140	141	142
2-1	2-2	2-3	2-4
143	144	145	146
3-1	3-2	3-3	3-4
147	148	149	150
4-1	4-2	4-3	4-4
151	152	153	154
SF1	SF2	SF3	SF4
155	156	157	158

1kw トツ 4台4色
SF-4 26° 2台 /SF-4 zoom 2台

荘銀タクト鶴岡
 DMX一覧

フルカラーLED	下手					中央					上手				
L H	I	R	G	B	W	I	R	G	B	W	I	R	G	B	W
	270	271	272	273	274	275	276	277	278	279	280	281	282	283	284

FLHC										
1	2	3		4	5	6		7	8	9
232	233	234		386	387	388		389	390	391

上LHC										
7	8	9		4	5	6		1	2	3
395	396	397		392	393	394		250	251	252

下 F C	13	14	15
	229	230	231
	10	11	12
	226	227	228
	7	8	9
	223	224	225
	4	5	6
	220	221	222
	1	2	3
	217	218	219

上 F C	13	14	15
	247	248	249
	10	11	12
	244	245	246
	7	8	9
	241	242	243
	4	5	6
	238	239	240
	1	2	3
	235	236	237

舞台 下前 F C	1	2	3

舞台 上前 F C	1	2	3

舞台 下前WC	1	2

※DMX NO.が非表示のコンセントは移動型調光器にて他の回路と差し替えて使用。

舞台 上前WC	1	2

天井反射板	285	286	287	288	289	290	291	292	293	294	295	296	297	298	299	300	301	302	303	304	305	306	307
	308	309	310	311	312	313	314	315	316	317	318	319	320	321	322	323	324	325	326	327	328	329	330
	331	332	333	334	335	336	337	338	339	340	341	342	343	344	345	346	347	348					

その他	1Bo 上下端					袖明かり			
						4Sus		3Sus	
						下	上	下	上
	I	R	G	B	W				
	501	502	503	504	505	509	510	511	512

使用可能DMX
400～500

DMX c h一覧表

場所	DMX	詳細	備考
1B 下	1	I	作業灯1
	2	R	↓
	3	G	↓
	4	B	↓
	5	W	↓
1B 中	6	I	↓
	7	R	↓
	8	G	↓
	9	B	↓
	10	W	↓
1B 上	11	I	↓
	12	R	↓
	13	G	↓
	14	B	↓
	15	W	↓
2B 下	16	I	作業灯2
	17	R	↓
	18	G	↓
	19	B	↓
	20	W	↓
2B 中	21	I	↓
	22	R	↓
	23	G	↓
	24	B	↓
	25	W	↓
2B 上	26	I	↓
	27	R	↓
	28	G	↓
	29	B	↓
	30	W	↓
1BR	31	B R 1-1	
	32	B R 1-2	
	33	B R 1-3	
	34	B R 1-4	
	35	BR 2-1	
	36	BR 2-2	
	37	BR 2-3	
	38	BR 2-4	
	39	BR 3-1	
	40	BR 3-2	
	41	BR 3-3	
	42	BR 3-4	
	43	BR 4-1	
	44	BR 4-2	
	45	BR 4-3	
	46	BR 4-4	
	47	BR 5-1	
	48	BR 5-2	
	49	BR 5-3	
	50	BR 5-4	
	51	BR 6-1	
	52	BR 6-2	
	53	BR 6-3	
	54	BR 6-4	
	55	BR 7-1	
	56	BR 7-2	
	57	BR 7-3	
	58	BR 7-4	
2SUS	59	2S 1-1	
	60	2S 1-2	
	61	2S 1-3	
	62	2S 1-4	
	63	2S 2-1	
	64	2S 2-2	

場所	DMX	詳細	備考
2SUS	65	2S 2-3	
	66	2S 2-4	
	67	2S 3-1	
	68	2S 3-2	
	69	2S 3-3	
	70	2S 3-4	
	71	2S 4-1	
	72	2S 4-2	
	73	2S 4-3	
	74	2S 4-4	
3SUS	75	2S 5-1	
	76	2S 5-2	
	77	2S 5-3	
	78	2S 5-4	
	79	3S 1-1	
	80	3S 1-2	
	81	3S 1-3	
	82	3S 1-4	
	83	3S 2-1	
	84	3S 2-2	
	85	3S 2-3	
	86	3S 2-4	
	87	3S 3-1	
	88	3S 3-2	
	89	3S 3-3	
	90	3S 3-4	
	91	3S 4-1	
	92	3S 4-2	
	93	3S 4-3	
	94	3S 4-4	
	95	3S 5-1	
	96	3S 5-2	
	97	3S 5-3	
	98	3S 5-4	
4SUS	99	4S 1-1	
	100	4S 1-2	
	101	4S 1-3	
	102	4S 1-4	
	103	4S 2-1	
	104	4S 2-2	
	105	4S 2-3	
	106	4S 2-4	
	107	4S 3-1	
	108	4S 3-2	
	109	4S 3-3	
	110	4S 3-4	
	111	4S 4-1	
	112	4S 4-2	
	113	4S 4-3	
	114	4S 4-4	
	115	4S 5-1	
	116	4S 5-2	
	117	4S 5-3	
	118	4S 5-4	
FR 下手	119	FR 1-1	
	120	FR 1-2	
	121	FR 1-3	
	122	FR 1-4	
	123	FR 2-1	
	124	FR 2-2	
	125	FR 2-3	
	126	FR 2-4	
	127	FR 3-1	
	128	FR 3-2	

場所	DMX	詳細	備考
FR 下手	129	FR 3-3	
	130	FR 3-4	
	131	FR 4-1	
	132	FR 4-2	
	133	FR 4-3	
	134	FR 4-4	
	135	FR SF4-1	
	136	FR SF4-2	
	137	FR SF4zoom1	
	138	FR SF4zoom2	
F R 上手	139	FR1-1	
	140	FR1-2	
	141	FR1-3	
	142	FR1-4	
	143	FR2-1	
	144	FR2-2	
	145	FR2-3	
	146	FR2-4	
	147	FR3-1	
	148	FR3-2	
	149	FR3-3	
	150	FR3-4	
	151	FR4-1	
	152	FR4-2	
	153	FR4-3	
	154	FR4-4	
	155	F R SF4-1	
	156	F R SF4-2	
	157	FR SF4zoom1	
	158	FR SF4zoom2	
1CL	159	上段 1	
	160	上段 2	
	161	下段 1	
	162	下段 2	
	163	上段 3	
	164	上段 4	
	165	下段 3	
	166	下段 4	
	167	上段 5	
	168	上段 6	
	169	下段 5	
	170	下段 6	
	171	下 SF-4	
	172	上段 7	
	173	上段 8	
	174	下段 7	
	175	下段 8	
	176	上段 9	
	177	上段 10	
	178	下段 9	
	179	下段 10	
	180	上 SF-4	
	181	上段 11	
	182	上段 12	
	183	下段 11	
	184	下段 12	
	185	上段 13	
	186	上段 14	
	187	下段 13	
	188	下段 14	
	189	上段 15	
	190	上段 16	
	191	下段 15	
	192	下段 16	

場所	DMX	詳細	備考
2CL	193	下1	
	194	下2	
	195	下3	
	196	下4	
	197	下5	
	198	下6	
	199	上1	
	200	上2	
	201	上3	
	202	上4	
	203	上5	
	204	上6	
PS	205	下1	
	206	下2	
	207	下3	
	208	下4	
	209	上1	
	210	上2	
	211	上3	
	212	上4	
	213	中1	
	214	中2	
	215	中3	
	216		
フロア 下手	217	FC 1	
	218	FC 2	
	219	FC 3	
	220	FC 4	
	221	FC 5	
	222	FC 6	
	223	FC 7	
	224	FC 8	
	225	FC 9	
	226	FC 10	
	227	FC 11	
	228	FC 12	
	229	FC 13	
	230	FC 14	
	231	FC 15	
	232	LHC 1	
	233	LHC 2	
	234	LHC 3	
フロア 上手	235	FC 1	
	236	FC 2	
	237	FC 3	
	238	FC 4	
	239	FC 5	
	240	FC 6	
	241	FC 7	
	242	FC 8	
	243	FC 9	
	244	FC 10	
	245	FC 11	
	246	FC 12	
	247	FC 13	
	248	FC 14	
	249	FC 15	
	250	LHC 1	
	251	LHC 2	
	252	LHC 3	
	253		
	254		
UH 下	255	I	
	256	R	

DMX c h一覧表

場所	DMX	詳細	備考
U H 下	257	G	
	258	B	
	259	W	
U H 中	260	I	
	261	R	
	262	G	
	263	B	
	264	W	
U H 上	265	I	
	266	R	
	267	G	
	268	B	
	269	W	
L H 下	270	I	
	271	R	
	272	G	
	273	B	
	274	W	
L H 中	275	I	
	276	R	
	277	G	
	278	B	
	279	W	
L H 上	280	I	
	281	R	
	282	G	
	283	B	
	284	W	
天反DL	285	作業灯 3	天反 D L
	286	↓	
	287	↓	
	288	↓	
	289	↓	
	290	↓	
	291	↓	
	292	↓	
	293	↓	
	294	↓	
	295	↓	
	296	↓	
	297	↓	
	298	↓	
	299	↓	
	300	↓	
	301	↓	
	302	↓	
	303	↓	
	304	↓	
	305	↓	
	306	↓	
	307	↓	
	308	↓	
	309	↓	
	310	↓	
	311	↓	
	312	↓	
	313	↓	
	314	↓	
	315	↓	
	316	↓	
	317	↓	
	318	↓	
	319	↓	
	320	↓	

場所	DMX	詳細	備考
天反DL	321	作業灯3	作業灯3
	322	↓	
	323	↓	
	324	↓	
	325	↓	
	326	↓	
	327	↓	
	328	↓	
	329	↓	
	330	↓	
	331	↓	
	332	↓	
	333	↓	
	334	↓	
	335	↓	
	336	↓	
	337	↓	
	338	↓	
	339	↓	
	340	↓	
客席DL	341	↓	
	342	↓	
	343	↓	
	344	↓	
	345	↓	
	346	↓	
	347	↓	
	348	↓	
	349	作業灯 4	客席 D L
	350	↓	
	351	↓	
	352	↓	
	353	↓	
	354	↓	
GM 連動	355	↓	
	356	↓	
	357	↓	
	358	↓	
	359	↓	
	360	↓	
	361	↓	
	362	↓	
	363	↓	
	364	↓	非常灯 連動
	365	CH 1	
	366	CH 2	
	367	CH 3	
	368	CH 4	
	369	CH 5	
	370	CH 6	
	371		
	372		
	373		
	374		
	375		
	376		
	377		
	378		
	379		
	380		
	381		
	382		
	383		
	384		

場所	DMX	詳細	備考
フロア 下手	385		
	386	LHC 4	
	387	LHC 5	
	388	LHC 6	
	389	LHC 7	
	390	LHC 8	
	391	LHC 8	
フロア 上手	392	LHC 4	
	393	LHC 5	
	394	LHC 6	
	395	LHC 7	
	396	LHC 8	
	397	LHC 8	
	398		
	399		
	400		
	401		
	402		
	403		
	404		
	405		
	406		
	407		
	408		
	409		
	410		
	411		
	412		
	413		
	414		
	415		
	416		
	417		
	418		
	419		
	420		
	421		
	422		
	423		
	424		
	425		
	426		
	427		
	428		
	429		
	430		
	431		
	432		
	433		
	434		
	435		
	436		
	437		
	438		
	439		
	440		
	441		
	442		
	443		
	444		
	445		
	446		
	447		
	448		

場所	DMX	詳細	備考
	449		
	450		
	451		
	452		
	453		
	454		
	455		
	456		
	457		
	458		
	459		
	460		
	461		
	462		
	463		
	464		
	465		
	466		
	467		
	468		
	469		
	470		
	471		
	472		
	473		
	474		
	475		
	476		
	477		
	478		
	479		
	480		
	481		
	482		
	483		
	484		
	485		
	486		
	487		
	488		
	489		
	490		
	491		
	492		
	493		
	494		
	495		
	496		
	497		
	498		
	499		
	500		
1 B 上下端	501	I	
	502	R	
	503	G	
	504	B	
	505	W	
	506		
	507		
	508		
	509	4Sus 下	LEDフレネル
	510	4Sus 上	LEDフレネル
	511	3Su s 下	LEDフレネル
	512	3Su s 上	LEDフレネル